

Michelman® Priming Solution Indicator

Category : Fluid , Other Engineering Material , Additive/Filler for Polymer

Material Notes:

Description: Indicator solution for primed paper substrates. Yellow to orange liquid turning blue in presence of ILP and Sapphire coated substrates. Usage: Priming Solution Indicator is used to prove the presence of primer solution on the sheet. Application Data: 1) Using a graduated eyedropper (pipette), dispense 10 drops of the indicator on the treated sheet. 2) Stream the indicator across the length and width of the sheet, including edges. Wait 30 seconds, then blot the excess with an absorbent towel. 3) Check color change to light blue, indicating the presence of the primer solution. Information provided by Michelman®

Order this product through the following link:

http://www.lookpolymers.com/polymer_Michelman-Priming-Solution-Indicator.php

Physical Properties	Metric	English	Comments
Specific Gravity	0.790 - 0.800 g/cc	0.790 - 0.800 g/cc	
Volatiles	99.01 - 100 %	99.01 - 100 %	
Brookfield Viscosity	<= 50 cP	<= 50 cP	Spindle # 3, rpm 60

Descriptive Properties	Value	Comments
Appearance	Yellow to orange liquid	

Contact Songhan Plastic Technology Co.,Ltd.

Website : www.lookpolymers.com

Email : sales@lookpolymers.com

Tel : +86 021-51131842

Mobile : +86 13061808058

Skype : lookpolymers

Address : United North Road 215, Fengxian District, Shanghai City, China